



AIR CONDITIONING MEDIUM TEMP REFRIGERATION COMPRESSORS

06D

ITEM	PART DESCRIPTION	06DR109	06DR013	06DR316	06DR718	06DR820
		6D21 2 CYL	4 CYL	6D43 4 CYL	6D47 4 CYL	6D48 4 CYL
REPLACEMENT COMPRESSOR GROUP						
	208/230—3-60	06DR1096GA3200	06DR0136CA3200	06DR3166CA3200	06DR7186DA3200	06DR8206DA3200
	400/460—3-50/60	06DR1096GA3600	06DR0136CA3600	06DR3166CA3600	06DR7186DA3600	06DR8206DA3600
	575—3-60	06DR1096GC3100	06DR0136CA3100	06DR3166CA3100	06DR7186DA3100	06DR8206DA3100
TERMINAL PLATE & BOX GROUP						
1 & 2	TERM. BOX & COVER KIT(3x 5x 6)	06DA660075	→	→	→	→
	1 OR 2 OV/LDS,1PH,3PH XL					
1 & 2	TERM. BOX & COVER KIT(3.4x6x6)	06DA660078	→	→	→	→
	UP TO 3 OV/LDS ,3PH XL					
1 & 2	TERM. BOX & COVER KIT(3 x6 x6)	06DA660088	→	→	→	→
	UP TO 6 OV/LDS,3PH PW					
EACH TERMINAL BOX & COVER KIT ALSO CONTAINS: LABELS, INSULATION AND MOUNTING HARDWARE						
3	NI TERMINAL PLATE PACKAGE	06DA660045	→	→	→	→
	INCLUDES ITEMS 3A—3H					
3A	TERMINAL PLATE ASSY(6 PIN)	NSS	→	→	→	→
	INCLUDES ITEMS 3B—3E					
3B	PHASE BARRIER(PLASTIC)	06DA503674	→	→	→	→
3C	NUT, TERMINAL(BRASS)	(6)06DA503262	(6) →	(6) →	(6) →	(6) →
3D	WASHER, LOCKTOOTH	(6)AU29AR171	(6) →	(6) →	(6) →	(6) →
3E	SPACER SLEEVE (BRASS)	(6)06DA502333	(6) →	(6) →	(6) →	(6) →
3F	GASKET, TERMINAL PLATE	6D40-1061	→	→	→	→
3G	NI SPLICE	(2)NSS	(2) →	(2) →	(2) →	(2) →
3H	NI SCREW, TERMINAL PLATE MTG	(4)NSS	(4) →	(4) →	(4) →	(4) →
4B	GROMMET, MOTOR LEAD	6D40-1311	→	→	→	→
5	NI TERMINAL PACKAGE	06DA660095	→	→	→	→
	INCLUDES					
	NI TERMINAL NUT & SET SCREW	(6)SEE NOTE	(6) →	(6) →	(6) →	(6) →
NOTE: FOR USE ON POWER LEADS THROUGH #5 WIRE GAUGE.						

NOTE: See "Catalog Notes" on last page for explanation of symbolism.



AIR CONDITIONING MEDIUM TEMP REFRIGERATION COMPRESSORS

06D

ITEM		PART DESCRIPTION	06DR109	06DR013	06DR316	06DR718	06DR820
			6D21 2 CYL	4 CYL	6D43 4 CYL	6D47 4 CYL	6D48 4 CYL
OVERLOAD GROUP							
5	NI	VOLTAGE CODE VOLTAGE					
		0300 230—1-60	HN69GZ037	HN69GZ301	X	HN69GZ301	X
		* 0400 200—3-60	(2)HN69GZ007	(2)HN69GZ053	(2)HN69GZ024	(2) →	(2)HN69GZ306
		* 0500 230—3-60	(2)HN69GZ039	(2)HN69GZ037	(2)HN69GZ031	(2) →	(2)HN69GZ214
		1200 208/230—3-60	X	X	X	X	(2)HN69GZ306
		* 0600 400/460—3-50/60	(2)HN69GZ015	(2)HN69GZ012	(2)HN69GZ014	(2) →	(2)HN69GZ025
		* 0100 575—3-60	(2)HN69GZ012	(2)HN69GZ011	(2)HN69GZ032	(2) →	(2)HN69GZ053
		0800 220—3-50	(2)HN69GZ012	(2)HN69GZ053	(2) →	(2)HN69GZ004	X
		1300 380—3-60	X	X	X	X	X
		1400 208—3-60 PW	X	X	X	X	X
		1500 230—3-60 PW	X	X	X	X	X
		1800 230—3-50 PW	X	X	X	X	X
		3100 575—3-60	(2)HN69GZ011	(2)HN69GZ012	(2)HN69GZ032	(2) →	(2)HN69GZ037
		3200 208/230—3-60 XL	(2)HN69GZ007	(2)HN69GZ004	(2)HN69GZ024	(2) →	(2)HN69GZ214
		3400 220—3-50 XL	X	X	X	(2)HN69GZ031	X
		3600 400/460—3-50/60	(2)HN69GZ015	(2)HN69GZ012	(2)HN69GZ014	(2) →	(2)HN69GZ038
		3900 415—3-50	(2)HN69GZ015	(2)HN69GZ012	(2)HN69GZ014	(2) →	(2)HN69GZ038
NOTE: * IF ORIGINAL O/L IS FURNAS CONTACT CARRIER FOR HTR OR O/L NO..							
7	NI	THERMOSTAT PACKAGE	X	X	X	X	X
		INCLUDES ITEMS 8A—8E					
8A		INSULATOR,THERMAL (FISH PAPER)	X	X	X	X	X
8B		THERMOSTAT (OPEN 160 F)	X	X	X	X	X
8C		SLEEVE,THERMOSTAT (FISH PAPER)	X	X	X	X	X
8D		WASHER (1-1/2 O.D.STEEL)	X	X	X	X	X
8E		SPRING,THERMOSTAT(1.31 I.D.)	X	X	X	X	X
NOTE: THE ABOVE THERMOSTAT PACKAGE (ITEM 7) IS USED ON PART WIND START MODELS ONLY.							
9	NI	OVERLOAD SPACER PACKAGE(2PCS)	06DA660077	→	→	→	→
		WILL TAKE UP TO 6 OV/LDS					
		USED IN 5X6 & 6X8 TERM.BOX					
9	NI	OVERLOAD SPACER PACKAGE	06DA403052	→	→	→	→
		WILL TAKE UP TO 4 OV/LDS					
		USED IN 6X8 TERM.BOX					
9	NI	OVERLOAD SPACER PACKAGE	06DA403042	→	→	→	→
		WILL TAKE UP TO 2 OV/LDS					
		USED IN 6X6 TERM.BOX					
NOTE: OVERLOAD SPACER IS USED TO MOUNT O/L'S IN TERMINAL BOX.							

NOTE: See "Catalog Notes" on last page for explanation of symbolism.



AIR CONDITIONING MEDIUM TEMP REFRIGERATION COMPRESSORS

06D

ITEM	PART DESCRIPTION	06DR109	06DR013	06DR316	06DR718	06DR820
		6D21 2 CYL	4 CYL	6D43 4 CYL	6D47 4 CYL	6D48 4 CYL
	SERVICE VALVE GROUP					
12	NI SUCTION VALVE PACKAGE	06DA660061	06DA660064	→	→	06DA660065
	INCLUDES ITEMS 13—17					
13	SERVICE VALVE	EN07AA271	EN07AA348	→	→	NSS
14	GASKET, VALVE	6D23-1421	6D40-1131	→	→	6D68-1131
15	CAPSCREW, VALVE MOUNTING	(2)NSS	(2) →	(2) →	(2) →	(4) →
16	CAP, VALVE(MUELLER)	EN99ZA006	→	→	→	→
16A	CAP, VALVE(HENRY)	X	EN99ZA013	→	→	→
17	GASKET, VALVE CAP(MUELLER)	EN99ZA102	EN99ZA103	→	→	→
17A	GASKET, VALVE CAP(HENRY)	X	X	X	X	X
18	NI SUCTION VALVE PKG.(ALTERNATE)	06DA660083	X	X	X	06DA660090
	INCLUDES ITEMS 13—17					
13	SERVICE VALVE	EN07AA331	X	X	X	EN07EA041
14	GASKET, VALVE	6D23-1421	X	X	X	6D68-1131
15	CAPSCREW, VALVE MOUNTING	(2)NSS	X	X	X	(4)NSS
16	CAP, VALVE(MUELLER)	EN99ZA006	X	X	X	EN99ZA006
16A	CAP, VALVE(HENRY)	X	X	X	X	EN99ZA013
17	GASKET, VALVE CAP(MUELLER)	EN99ZA012	X	X	X	EN99ZA103
17A	GASKET, VALVE CAP(HENRY)	X	X	X	X	X
19	NI DISCHARGE VALVE PACKAGE	06DA660060	→	→	→	→
	INCLUDES ITEMS 20—24					
20	SERVICE VALVE(5/8ODS, 2BOLT)	EN32AA250	→	→	→	→
21	GASKET, VALVE (1.62 CTRS.)	6D23-1421	→	→	→	→
22	CAPSCREW, VALVE MOUNTING	(2)NSS	(2) →	(2) →	(2) →	(2) →
23	CAP, VALVE(MUELLER)	EN99ZA001	→	→	→	→
23A	CAP, VALVE(HENRY)	X	X	X	X	X
24	GASKET, VALVE CAP(MUELLER)	X	X	X	X	X
24A	GASKET, VALVE CAP(HENRY)	X	X	X	X	X
19	NI DISCHARGE VLV.PKG.(ALTERNATE)	06DA660059	06DA660061	→	→	→
	INCLUDES ITEMS 20—24.					
20	SERVICE VALVE(2 BOLT)	EN26AA211	NSS	→	→	→
21	GASKET, VALVE (1.62 CTRS.)	6D23-1421	→	→	→	→
22	CAPSCREW, VALVE MOUNTING	(2)NSS	(2) →	(2) →	(2) →	(2) →
23	CAP, VALVE(MUELLER)	EN99ZA001	→	→	→	→
23A	CAP, VALVE(HENRY)	X	X	X	X	X
24	GASKET, VALVE CAP(MUELLER)	EN99ZA102	EN99ZA103	→	→	→
24A	GASKET, VALVE CAP(HENRY)	X	X	X	X	X

NOTE: See "Catalog Notes" on last page for explanation of symbolism.

ITEM	PART DESCRIPTION	06DR109	06DR013	06DR316	06DR718	06DR820
		6D21 2 CYL	4 CYL	6D43 4 CYL	6D47 4 CYL	6D48 4 CYL
COMPRESSOR BODY GROUP						
	NI PAINT (SEA FOAM GREEN)	PH23QK016	→	→	→	→
25	NI GASKET SET (#)	6D43-172	→	→	→	→
26	HEAD,CYLINDER(CENTER)	6D40-2163	X	X	X	X
27	HEAD,CYLINDER(NON/UNL)	X	(2)6D40-2163	(2) →	(2) →	(2) →
30	GASKET,CYLINDER HEAD(CENTER)	6D40-1053	X	X	X	X
31	GASKET,CYLINDER HEAD(NON/UNLO)	X	(2)6D40-1053	(2) →	(2) →	(2) →
34	CAPSCREW,CYLINDER HEAD(PLAIN)	(8)AA06BR237	(12) →	(12) →	(12) →	(12) →
36	SCREEN ASSEMBLY,OIL FILTER	6D40-103	→	→	→	→
37	PLUG,OIL BY—PASS(5/8-18 X 1/4)	X	5F20-1311	→	→	→
38	GASKET,OIL BY—PASS PLUG (5/8)	X	AU51YA011	→	→	→
39	TUBE,OIL SUCTION	05DA500283	6D40-1092	→	6D48-1092	→
40	VALVE ASSEMBLY,OIL RELIEF	6D23-522	→	→	→	→
	INCLUDES ITEMS 41					
41	NI NUT,COMPRESSION	X	X	X	X	X
42	SIGHTGLASS ASSEMBLY(1-1/2-18)	5F20-152	→	→	→	→
	INCLUDES ITEM 43					
43	GASKET,SIGHTGLASS	5F20-1631	→	→	→	→
42	SIGHTGLASS (SPECIAL) 3/4 NPT	X	X	X	X	X
42B	ADAPTOR (1 1/2-18 X 1 1/8 ODS)	30HH401051	→	→	→	→
44	KIT,STATOR LOCKING	X	X	X	X	X
45	COVER,BOTTOM	6D40-1033	6D48-1274	→	6D40-1033	→
46	GASKET,BOTTOM COVER	6D40-1043	→	→	→	→
47	CAPSCREW,BOTTOM PLATE	(16)AA06BR229	(16) →	(16) →	(16) →	(16) →
48	FOOT,COMPRESSOR(MOTOR END)	6D40-1042	→	→	6D48-2063	→
49	CAPSCREW,COMPRESSOR FOOT	(2)AA06BR229	(2) →	(2) →	(2) →	(2) →
49A	WASHER,EVERLOCK	(2)AU27AR241	(2) →	(2) →	(2) →	(2) →
50	COVER,MOTOR END @	6D23-1084	6D48-1024	→	→	06EA502224
51	GASKET,MOTOR END COVER	6D23-1063	6F25-1013	→	→	→
52	CAPSCREW,MOTOR END COVER	(18)AA06BR232	(18)AA06BR262	(18) →	(18) →	(18) →
53	STRAINER,SUCTION(CYLINDER)	6D23-112	6D40-112	→	X	X
53	STRAINER,SUCTION(FLAT TYPE)	X	6D48-303	→	→	→
54	PLATE,BAFFLE(OLDER UNITS ONLY)	6D23-1172	6D40-1172	→	X	X
55	ROLLPIN(STATOR TO CRANKCASE)	AX14CA135	→	→	→	→
56	VALVE ASSEMBLY,CHECK	6D40-162	→	→	→	→
57	PLUG,PIPE(1/4"HEX HEAD)	(3)CA63AA051	(4) →	(4) →	(4) →	(4) →
58	VALVE ASSEMBLY,LOW PRESS.CONN.	06DA403844	→	→	→	→
59	CAP,VALVE(7/16-20)	DD19CA061	→	→	→	→
# GASKET SET 6D43-172 CONTAINS ITEMS 3F,14,30,31,38,46,51,73,80,108 & 200 . ALL AVAILABLE VERSIONS OF EACH ITEM ARE INCLUDED. QUANTITIES ARE SUFFICIENT FOR 2,4 OR 6 CYLINDER .						
@ AN ALTERNATE COVER FOR 2 BOLT SUCTION VALVE IS 06DA505404 ON 109.						

NOTE: See "Catalog Notes" on last page for explanation of symbolism.

ITEM	PART DESCRIPTION	06DR109 6D21 2 CYL	06DR013 4 CYL	06DR316 6D43 4 CYL	06DR718 6D47 4 CYL	06DR820 6D48 4 CYL
PUMP END GROUP						
60	NI BEARING HEAD PACKAGE	6D68-952	→	→	→	→
	INCLUDES ITEMS 62-80					
BEARING HEAD PACKAGE HAS 1/8NPT CONNECTION FOR OIL SAFETY SWITCH WHICH IS NOT PART OF ITEM 60. ORDER SWITCH P529-2110 IF REQUIRED.						
62	BEARING HEAD ASSEMBLY	NSS	→	→	→	→
	INCLUDES ITEMS 63-69					
63	BEARING, HEAD	NSS	→	→	→	→
64	ROTOR, PUMP	NSS	→	→	→	→
65	VANE, PUMP	(2)NSS	(2) →	(2) →	(2) →	(2) →
66	SPRING, VANE	(2)NSS	(2) →	(2) →	(2) →	(2) →
67	GUIDE, SPRING	(2)NSS	(2) →	(2) →	(2) →	(2) →
68	RING, RETAINING	NSS	→	→	→	→
69	RING, ROTOR RETAINING	NSS	→	→	→	→
70	GASKET, CAPSCREW(5/16)	(4)AU51YA003	(4) →	(4) →	(4) →	(4) →
71	SCREW, HEX HEAD CAP (5/16-18)	(4)AA06GR199	(4) →	(4) →	(4) →	(4) →
72	PLATE, COVER	06DA502972	→	→	→	→
73	GASKET, COVER PLATE	6D40-1061	→	→	→	→
74	SPRING, GUIDE VANE	6D40-1112	→	→	→	→
75	VANE, GUIDE	6D40-1171	→	→	→	→
76	DRIVE SEGMENT, OIL PUMP	6D40-1191	→	→	→	→
77	SCREW, SOCKET HEAD	(2)NSS	(2) →	(2) →	(2) →	(2) →
78	LOCKWASHER	(2)NSS	(2) →	(2) →	(2) →	(2) →
79	SCREW, HEX HEAD CAP	(8)NSS	(8) →	(8) →	(8) →	(8) →
80	GASKET, BEARING HEAD	6D40-1022	→	→	→	→
DRIVE TRAIN GROUP						
81	SHAFT, ECCENTRIC	6D24-1094	06DA504874	→	X	X
81A	SHAFT, CRANKSHAFT	X	X	X	6D48-403	→
81B	NI SHAFT, ECCENTRIC .010 UNDERSIZE	X	X	X	06DA660079	→
OLDER UNDERSIZE SHAFTS ARE IDENTIFIED BY AN "A" STAMPED ON ONE OR BOTH ENDS OF SHAFT.						
NEWER UNDERSIZED SHAFTS ARE IDENTIFIED BY REFERRING TO DETAIL "C" ON PAGE 12 OF THIS CATALOG.						
82	SIDE SHIELD, ECCENTRIC STRAP	X	(2)06DA503033	(2) →	X	X
83	COUNTERWEIGHT, PUMP END	X	06DA503003	→	X	X
84	COUNTERWEIGHT, MOTOR END	X	06DA503023	→	X	X
85	THRUSTWASHER	6D23-1591	X	X	X	X
86	PIN, SPIROL(THRUSTWASHER)	X	X	X	X	X
87	LOCKWASHER, ROTOR(1.75DIA)	06DA503112	→	→	→	→
88	LOCKWASHER(5/8)SPT. STAR	06DA503102	→	→	→	→
89	TUBE ASSEMBLY, EQUALIZER	6D23-122	6D48-122	→	→	→
95	KEY, ROTOR(1/4X1/4X3)	AW01DA103	→	→	→	→

NOTE: See "Catalog Notes" on last page for explanation of symbolism.



AIR CONDITIONING MEDIUM TEMP REFRIGERATION COMPRESSORS

06D

ITEM	PART DESCRIPTION	06DR109	06DR013	06DR316	06DR718	06DR820
		6D21 2 CYL	4 CYL	6D43 4 CYL	6D47 4 CYL	6D48 4 CYL
DRIVE TRAIN GROUP CONT'D						
THE FOLLOWING FLAT TOP STANDARD AND OVERSIZED PISTONS ARE FOR USE IN COMPRESSOR MODELS: 06D----- 0100,0400,0500,0600&1200 ONLY.						
90	NI PISTON & PIN PACKAGE (CONTOURED TOP)(2.00 DIA.BORE) INCLUDES ITEMS 91-93	(2)06DR660025	(4)06DR660026	(4)06DR660027	(4)06DR660025	(4)06DR660028
91	PISTON	NSS	→	→	→	→
92	PISTON,PIN	NSS	→	→	→	→
93	RETAINING RING,PISTON PIN	(2)6D43-1651	(2) →	(2) →	(2) →	(2) →
94	WASHER,CURVED SPRING	(4)5D20-1321	X	X	X	X
90	NI PISTON & PIN ASSEMBLY * (.020 OVERSIZE) (2.020 BORE) (CONTOURED TOP) INCLUDES ITEMS 91-93	06DR660033	06DR660034	06DR660035	06DR660033	06DR660036
91	PISTON	NSS	→	→	→	→
92	PIN,PISTON	NSS	→	→	→	→
93	RETAINING RING,PISTON	(2)6D43-1651	(2) →	(2) →	(2) →	(2) →
90	NI PISTON & PIN PKG (FLAT TOP DESIGN)(2.00 BORE) INCLUDES ITEMS 91-93	6D43-962	NLA	6D68-962	6D43-962	6D44-962
91	PISTON	NSS	→	→	→	→
92	PIN,PISTON	NSS	→	→	→	→
93	RETAINING RING,PISTON PIN	(2)6D43-1651	(2) →	(2) →	(2) →	(2) →
90	NI PISTON & PIN PKG (FLAT TOP DESIGN).020 OVERSIZE INCLUDES ITEMS 91-93	06DA660067	NLA	06DA660066	06DA660067	06DA660068
91	PISTON	NSS	NLA	NSS	→	→
92	PIN,PISTON	NSS	NLA	NSS	→	→
93	RETAINING RING,PISTON PIN	(2)6D43-1651	(2) →	(2) →	(2) →	(2) →
96	ECCENTRIC STRAP	(2)5D40-1372	(4) →	(4) →	X	X
96	NI CONNECTING ROD & CAP ASSEMBLY INCLUDES ITEMS 97-99	X	X	X	(4)06DA660041	(4)06DA660086
97	CONNECTING ROD & CAP	X	X	X	NSS	→
98	CAPSCREW,SELFLOCKING	X	X	X	(2)06DA502763	(2) →
99	DOWEL PIN	X	X	X	(2)7J1-6032	(2) →
96	NI CONN ROD & CAP ASSY(-.010) INCLUDES ITEMS 97-99	X	X	X	06DA660048	06DA660087
97	CONNECTION ROD & CAP	X	X	X	NSS	NSS
98	CAPSCREW,SELF LOCKING	X	X	X	(2)06DA502763	(2) →
99	PIN,DOWEL	X	X	X	(2)7J1-6032	(2) →
100	RING,COMPRESSION(2.00 DIA)	(2)AU50CP355	(4) →	(4) →	(4) →	(4) →
100	RING,COMPRESSION(PKG OF 12) (.020 OVERSIZE) (NOTE)	06DA660069	→	→	→	→
100	RING,COMPRESSION (1.81 DIA.)	X	(4)AU50CP350	X	X	X
101	RING,OIL(2.00 DIA) (NOTE)	(2)AU50CP245	(4) →	(4) →	(4) →	(4) →
101	RING,OIL(2.00 DIA) (+.020) PKG OF 12 RINGS (+.020)	06DA660070	→	→	→	→
101	RING,OIL (1.81 DIA.)	X	(4)AU50CP250	X	X	X
CURRENT PRODUCTION COMPRESSORS NO LONGER USE OIL RINGS.						
(*) IDENTIFIED BY "020" STAMPED ON CYLINDER DECK NEXT TO EACH OVER- SIZED PISTON.CHECK NEAR EACH,NOT ALL MAY BE MARKED,ONLY 1 OR 2.						

NOTE: See "Catalog Notes" on last page for explanation of symbolism.

ITEM		PART DESCRIPTION	06DR109	06DR013	06DR316	06DR718	06DR820
			6D21 2 CYL	4 CYL	6D43 4 CYL	6D47 4 CYL	6D48 4 CYL
VALVE PLATE GROUP							
102	NI	VALVE PLATE PACKAGE	06DA660094	→	→	→	→
		INCLUDES ITEMS 103–108					
103		VALVE PLATE ASSMBLY	NSS				
		INCLUDES ITEMS 104–107					
104		VALVE, DISCHARGE	(2)06DA502913	(2) →	(2) →	(2) →	(2) →
105		STOP, DISCHARGE VALVE	(2)06DA502893	(2) →	(2) →	(2) →	(2) →
106		SCREW, HEX HEAD	(4)AB06GQ164	(4) →	(4) →	(4) →	(4) →
107		LOCKWASHER	(4)AU61ML171	(4) →	(4) →	(4) →	(4) →
108		GASKET, VALVE PLATE	6D43-1073	→	→	→	→
31		GASKET, CYLINDER HEAD	6D40-1053	→	→	→	→
109		VALVE, SUCTION	(2)06DA502903	(2) →	(2) →	(2) →	(2) →
110		SPRING, SUCTION VALVE POSITION	(2)NSS	(2) →	(2) →	(2) →	(2) →
111		GASKET, VALVE PLATE (STEEL)	06DA502923	→	→	→	→
30		GASKET, CYLINDER HEAD	6D68-1053	→	→	→	→
112		DOWEL, SUCTION VALVE	(4)7J1-6032	(8) →	(8) →	(8) →	(8) →
102B		VALVE PLATE PKG(R.H.)(1.81 BORE)	X	06DR660008	X	X	X
102C		VALVE PLT PKG(L.H.)(1.81 BORE)	X	06DR660009	X	X	X
NOTE: R. H. OR L. H. IS DETERMINED BY VIEWING COMPR FROM PUMP END. SUCTION PORT IN VALVE PLATE IS TO BE AT MOTOR END OF PLATE.							
		EACH INCLUDES ITEMS 103–110					
103		VALVE PLATE ASSY	X	NSS	X	X	X
		INCLUDES ITEMS 104–107					
104		VALVE DISCHARGE	X	(2)6D75-1062	X	X	X
105		STOP, DISCHARGE VALVE	X	(2)6D75-1052	X	X	X
106		SCREW, HEX HD 1/4–28 X 3/8 LG	X	(4)AB06GQ164	X	X	X
107		LOCK WASHER	X	(4)AU61ML171	X	X	X
108		GASKET, VALVE PLATE	X	6D40-1073	X	X	X
31		GASKET, CYLINDER HEAD (PLAIN)	X	6D40-1053	X	X	X
109		VALVE, SUCTION (1.81 BORE)	X	(2)6D45-1072	X	X	X
ACCESSORY GROUP							
		CRANKCASE HEATER PACKAGES					
126	NI	STRAP ON 115V, 50W, 39" LEAD	06DA660091	→	→	X	X
126	NI	STRAP ON 230V, 50W, 39" LEAD	06DA660092	→	→	X	X
126	NI	STRAP ON 230V, 100W, 52" LEAD	X	HT32BD346	→	X	X
		INCLUDES ITEM 127					
127	NI	BRACKET	07DA500011	→	→	→	
		INSERTION TYPE(CARTRIDGE)					
128	NI	120V, 180W, 73" LEAD	X	X	X	X	38AQ660003
128	NI	240V, 180W, 73" LEAD	X	X	X	38AQ660004	→
128	NI	480V, 125W, 73" LEAD	X	X	X	06DA660076	→
		INCLUDES ITEM 129					
129	NI	CLIP	X	X	X	AS81VF056	→
130	NI	SOLID MOUNT SPACER PACKAGE	30HR070-1071	→	→	→	→
131	NI	COMPRESSOR INTERCONNECTION PKG	06DA900072	→	→	→	→
		INCLUDES ITEMS 132–133					
132	NI	ADAPTER(1 1/2-18 X 1 1/8 ODS)	(2)30HH401051	(2) →	(2) →	(2) →	(2) →
133	NI	GASKET	(2)5F20-1631	(2) →	(2) →	(2) →	(2) →
SOME 06DR109 MODELS MAY HAVE A 3/4 NPT SIGHT GLASS CONNECTION SEE PMB 87-42 FOR INSTRUCTIONS.							
138	NI	MUFFLER	06DA605594	→	→	→	06DA605614
139	NI	MOUNTING PLATE KIT	06EA660096	→	→	→	→
140	NI	SUSPENSION KIT	06DA660058	06DA660056	→	→	→
		INCLUDES ITEMS 141–147					
141	NI	SPRING, MOUNTING	(4)50K12-1231	(4)50K4-1231	(4) →	(4) →	(4) →
142	NI	RETAINING, SPRING	(2)50K4-1221	(2) →	(2) →	(2) →	(2) →
143	NI	NUT, LOCK	(4)AT61JA241	(4) →	(4) →	(4) →	(4) →
144	NI	SNUBBER	(4)6D73-2241	(4) →	(4) →	(4) →	(4) →
145		CUP, SNUBBER	(4)6D73-2251	(4) →	(4) →	(4) →	(4) →

NOTE: See "Catalog Notes" on last page for explanation of symbolism.

ITEM		PART DESCRIPTION	06DR109	06DR013	06DR316	06DR718	06DR820
			6D23 2 CYL	4 CYL	6D43 4 CYL	6D47 4 CYL	6D48 4 CYL
ACCESSORY GROUP CONT'D.							
146	NI	STUD	(4)NSS	(4) →	(4) →	(4) →	(4) →
147	NI	NUT, FLANGED	(8)NSS	(8) →	(8) →	(8) →	(8) →
180	NI	CYLINDER HEAD COOLING PKG	X	06DR660014	→	→	→
		INCLUDES ITEMS 181—190					
181	NI	MOTOR(1/20 H.P.,208/230-1-60)	X	HC27GB230	→	→	→
182	NI	FAN REPLACEMENT PKG	X	06DR660012	→	→	→
		INCLUDES ITEMS 183—185					
183	NI	FAN	X	LA01AA102	→	→	→
184	NI	BUSHING	X	P251-0064	→	→	→
185	NI	SET SCREW	X	AE54FR167	→	→	→
186	NI	FAN GUARD & MOTOR MTG ASSY	X	06DA401773	→	→	→
187	NI	COVER ASSY,FAN GUARD	X	06DA401763	→	→	→
188	NI	ADAPTER,CONDUIT	X	HW60EZ158	→	→	→
189	NI	WASHER,3/8 PLATE	X	(8)AU02AB242	(8) →	(8) →	(8) →
190	NI	NUT,3/8 HEX	X	(4)AT39AB241	(4) →	(4) →	(4) →

NOTE: See "Catalog Notes" on last page for explanation of symbolism.